

# EVO-813W LIGHT DRILL TEMPLATE

PRINT 100% OR 1 TO 1. VERIFY 2.00"  
USE TEMPLATE TO DRILL LIGHT MOUNTING HOLES.  
2 HOLES @ 2.00" ARE LIGHT BOLT HOLES. THESE WILL ALWAYS NEED TO BE DRILLED  
LARGE SET OF 4 HOLES ARE WIRING ROUTING HOLES.  
DEPENDING ON LIGHT ORIENTATION ONLY 1 OF THE 4 WILL NEED TO BE DRILLED FOR WIRE.

